

# Cámaras de fotos

PRODUCTO	CÓDIGO DEL PRODUCTO	CODIGO EAN	PUNTOS
<b>CAMERAS COMPACTAS DIGITALES</b>			
<b>IXUS</b>			
IXUS 175 SL ESSENTIALS KIT	1094C014AA	8714574637129	1
IXUS 175 RED ESSENTIALS KIT	1097C012AA	8714574637136	1
IXUS 175 RED	1097C001AA	4549292057249	1
IXUS 175 SIL	1094C001AA	4549292057188	1
IXUS 180 BLK	1085C001AA	4549292056990	1
IXUS 180 RED	1088C001AA	4549292057058	1
IXUS 180 BLUE	1091C001AA	4549292057126	1
IXUS 285 HS BK	1076C001AA	4549292057478	1
IXUS 285 HS SIL	1079C001AA	4549292057539	1
IXUS 285 HS PURPLE	1082C001AA	4549292057591	1
<b>POWERSHOT D SERIES</b>			
POWERSHOT D30 BLUE	9337B011AA	8714574615998	1
POWERSHOT N2 WH	9770B002AA	4549292017465	1
<b>POWERSHOT G SERIES</b>			
POWERSHOT G1 X MARK II	9167B011AA	8714574615950	1
POWERSHOT G3X	0106C002AA	4549292034615	1
POWERSHOT G5X	0510C002AA	4549292052893	1
POWERSHOT G7X	9546B002AA	4549292020373	1
POWERSHOT G9X BLK	0511C002AA	4549292051773	1
POWERSHOT G9X SIL	0924C002AA	4549292051841	1
<b>POWERSHOT SX SERIES</b>			
POWERSHOT SX540 HS	1067C002AA	4549292056426	1
POWERSHOT SX420 IS BLK	1068C002AA	4549292056488	1
POWERSHOT SX420 IS RED	1069C002AA	4549292056556	1
POWERSHOT SX710 HS BLK + CS100 KIT	0109C027AA	8714574631424	1
POWERSHOT SX720 HS RED	1071C002BA	4549292056921	1
POWERSHOT SX720 HS BLK	1070C002BA	4549292056594	1
POWERSHOT SX60 HS	9543B002AA	4549292017380	1
POWERSHOT SX710 HS BLK	0109C002AA	4549292028980	1
POWERSHOT SX710 HS RED	0110C002AA	4549292029741	1
POWERSHOT SX610 HS BLK	0111C002AA	4549292030631	1
POWERSHOT SX610 HS RED	0113C002AA	4549292031096	1
POWERSHOT SX610 HS WH	0112C002AA	4549292031034	1
<b>IMPRESORAS SELPHY</b>			
SELPHY CP1200 WH PRINTING KIT	0600C012AA	8714574635972	1
SELPHY CP1200 BK PRINTING KIT	0599C013AA	8714574635941	1
SELPHY CP1000 WHT	0011C012AA	8714574630489	1
SELPHY CP1200 BLK	0599C002AA	4549292038514	1
SELPHY CP1200 WH	0600C002AA	4549292038552	1
<b>ACCESORIOS CAMARAS COMPACTAS</b>			
<b>BATERIA</b>			
BATERIA NB-CP2LH (CP1200)	0749C001AA	4549292045055	1
KIT ACCESORIOS SX7XX-6XX (FUNDA + BATERIA)	8724B008AA	8714574628967	1
BATERIA NB-13L (G7X)	9839B001AA	4549292020502	1
BATERIA NB-12L (N100/G1X MARKII)	9426B001AA	4549292009781	1
BATERIA NB-11LH (IXUS160-165-170-275/SX400-410)	9391B001AA	4549292004472	1
BATERIA NB-10L (SX40/50/60-G15/16-G1X)	5668B001AA	4960999796093	1
BATERIA NB-9L (IXUS1000/1100/500/510/PS N)	4722B001AA	4960999676586	1
BATERIA NB-8L (PSA3100/PSA3000/PSA3150)	4267B001AA	4960999661407	1
BATERIA NB-7L (G10/11/12-SX30IS)	3153B001AA	4960999620909	1
BATERIA NB-6LH(D30/SX170-240-710-530-610/S95-200)	8724B001AA	496099989952	1
BATERIA NB-5L (IXUS990IS-SX200/210/220/230-S100)	1135B001AB	4960999355160	1
BATERIA NB-5H	3216A002AA	4960999161570	1
BATERIA NB-4L (IXUS95/105/115/100/220/230/)	9763A001AB	4960999242439	1
BATERIA NB4-300 (A4XX-A8XX-A1XXX-A2100-SX20IS)	1171B002AB	4960999352343	1
BATERIA NB4-200	9227A002AA	4960999206523	1
BATERIA NB-3L	8456A001AB	4960999185729	1
BATERIA NB-1LH	7649A001BB	4960999048147	1
<b>ADAPTADOR/CARGADOR</b>			
ADAPTADOR CA-DC30E (G9X)	0993C001AA	4549292054446	1
ADAPTADOR CA ACK-800 (A1400/SX150-160)	7640A003AA	4960999044910	1
ADAPTADOR CP CA-PS700E	7875A003AA	4960999112237	1
ADAPTADOR COMPACTO CA-DC20	0754B001AA	4960999293417	1

ADAPTADOR MACRO LITE MLA-DC1	5970B001AA	4960999840178	1
ADAPTADOR CARGADOR CG-CP200	6203B001AA	4960999905723	1
ADAPTADOR ACK-DC50	3157B003AA	4960999620855	1
ADAPTADOR ACK-DC90 (IXUS160-165-170/275)	6216B003AA	4960999844169	1
ADAPTADOR ACK-DC80 (G1X/G16-15/SX50-40)	5667B003AA	4960999795935	1
ADAPTADOR ACK-DC70 (IXUS1000HS/PS N2)	4726B003AA	4960999676692	1
ADAPTADOR ACK-DC60 (PSA3100/PSA3000/PSA3150)	4266B003AA	4960999661223	1
CARGADOR CB-2LSE	6900A001AA	4960999004525	1
CARGADOR CB-2LYE (PS SX530HS/SX710 HS/SX610 HS)	2609B001AA	4960999571676	1
CARGADOR CB-2LXE (IXUS991S)	1134B001AA	4960999355191	1
CARGADOR CB-2LWE (E)	0764B001AA	4960999297897	1
CARGADOR CB-2LVE (IXUS95/105/115/100/220/230)	9765A001AA	4960999242453	1
CARGADOR CB-2LZE	3155B001AA	4960999620824	1
CARGADOR CB-2LHE (G7X)	9841B001AA	4549292020625	1
CARGADOR CB-2LUE	8458A001AA	4960999183848	1
CARGADOR CB-2LGE (N100)	9514B001AA	4549292009828	1
CARGADOR CBK4-300(E)	1169B003AA	4960999354194	1
CARGADOR CB-2LDE (IXUS125HS/240HS)	6214B001AA	4960999844091	1
CARGADOR CB-2LCE (G1X)	5670B001AA	4960999796130	1
CARGADOR BAT.CB-2LBE (IXUS1000/1100/500/510/PSN2)	4724B001AA	4960999676623	1
CARGADOR CB-2LAE (SX11S/SX101S/SX201S)	4269B001AA	4960999661193	1
CARGADOR CB-2LFE (IXUS160-165-170-275/SX410)	8420B001AA	4960999977324	1
KIT ADAPTADOR ACK-DC110 (G7X)	9838B003AA	4549292020694	1
KIT ADAPTADOR ACK-DC100 (N100)	9535B003AA	4549292009941	1
KIT ACCESORIOS ACK-DC40 (PS SX530HS-710-610)	2610B003AA	4960999571706	1
KIT ACCESORIOS ACK-DC30(E)SX230/S100/110	1137B003AA	4960999355221	1
KIT DE ACCESORIOS ACK-DC20 (E)	0766B003AA	4960999297927	1
KIT CA ACK-DC10	9226A003AA	4960999242491	1
ACOPLADOR CC DR-DC10	5190B001AA	4960999782959	1

## CABLES

CABLE DE VIDEO VC-200	4565A001AA	4960999162133	1
CABLE AV AVC-DC200	7021A001AA	4960999008578	1
CABLE AV AVC-DC400 (IXUS160-165-170-275)	2563B001AA	4960999570754	1
CABLE AV AVC-DC300	9371A001AA	4960999209913	1
CABLE INTERFAZ PIF-100	7419A001AA	4960999039176	1
CABLE INTERFAZ IFC-400PCU	9370A001AA	4960999209906	1
CABLE INTERFAZ IFC-200PCU	4566A001AA	4960999162065	1
CABLE INTERFAZ IFC-200MC	4568A001AA	4960999162119	1
CABLE INTERFAZ IFC-600PCU	1015C001AA	4549292054378	1

## ESTUCHES

FUNDA DCC-1890 (G9X)	0041X473	8714574632506	1
FUNDA DCC-1870 (G7X)	0040X554	8714574625607	1
ACCESSORY ORGANIZER (PS SX530-710-610-410)	0036X433	8714574583167	1
FUNDA DCC-1850 (G5X)	0041X472	8714574632490	1
FUNDA DCC-2300 (G3X)	0041X068	8714574628974	1
FUNDA DE SILICONA SJ-DC1 (D30)	9556B001AA	4549292012439	1
FUNDA SC-DC65A(G12&G11)RETRO	4049B001AA	4960999654683	1
FUNDA SC-DC70 (D10)	3915B001AA	4960999640297	1
FUNDA SC-DC75 (G1X)	5968B001AA	4960999819921	1
FUNDA SC-DC80 (D30/20)	6241B001AA	4960999844756	1
FUNDA DCC-1100 (IXUS1101S)	0030X832	8714574534596	1
FUNDA DCC-1550 VINTAGE BROWN (SX 280-270)	0038X511	8714574604824	1
FUNDA DCC-1550 VINTAGE BLACK (SX 280-270)	0038X179	8714574600116	1
FUNDA DCC-1800 (G1X)	0036X207	8714574580845	1
FUNDA DCC-1400 (S90)	0031X914	8714574542942	1
FUNDA DCC-1300 (IXUS125HS/240/230)	0035X471	8714574575810	1
FUNDA DCC-850 (PS SX520-SX530-50-40-30)	1872V639	8714574560380	1
FUNDA DCC-520 (A3400/A4000)	0036X253	8714574581217	1
FUNDA DCC-510 BLACK (PSA2400-2200/3300-3200)	0034X433	8714574569185	1
FUNDA RETRO DCC-75 (IXUS8701S)	1361V691	8714574527611	1
FUNDA DCC-1320 (IXUS 150-155-160-165/265)	0038X180	8714574605012	1
FUNDA DCC-420 (PS A3500/2600/2500)	0038X113	8714574600123	1
FUNDA DCC-1700 (IXUS1000HS)	0033X728	8714574558721	1
FUNDA DCC-1600 (G12)	0033X730	8714574558745	1
FUNDA DCC-1500 (SX600/280/270/260/240)	0032X600	8714574549088	1
FUNDA DCC-1450 (S200/120/110/95)	0033X729	8714574558738	1
FUNDA DCC-480 (PSA495)	0030X834	8714574534619	1
FUNDA DCC-750 (SX170/160/110)	1361V696	8714574527642	1
FUNDA DE CUERO DCC-60 (IXUS95/100/105/500/510)	0472V136	8714574943213	1
FUNDA DCC-1200 BLACK (IXUS100/120/130/220)	0030X833	8714574534602	1
FUNDA DCC-510 PNK (PS A3300-3200/2400-2300-2200)	0034X457	8714574570037	1
FUNDA DCC-1570 (PS SX700-SX710 HS-SX610 HS)	0039X577	8714574617244	1
FUNDA RETRO DCC-1820 (G1X MARK II)	0039X578	8714574617251	1
FUNDA DCC-520 RED (PS A3500-3400/2600-2500)	0036X397	8714574582818	1
FUNDA DCC-1920 BLK (PS S120)	0038X888	8714574610337	1
FUNDA DCC-1620 BLACK (G16-15)	0037X690	8714574592725	1

FUNDA DCC-1900 BLACK (S110)	0037X689	8714574592718	1
FUNDA DCC-1900 BROWN (S110)	0037X692	8714574592749	1
FUNDA DCC-1900 WHITE (S110)	0037X691	8714574592732	1
FUNDA DCC-1350 (IXUS160-165-170/255-265-275)	0038X112	8714574600130	1
FUNDA DCC-490 (PS A1300-1200/A810-800)	0034X434	87145745669192	1
FUNDA DCC-1370 (IXUS160-165-170/265-275)	0039X576	8714574617237	1
FUNDA DCC-510 RED (PS A3300-3200/2400-2300-2200)	0034X456	8714574570020	1
FUNDA DCC-520 BLUE (PS A3500-3400/2600-2500)	0036X398	8714574582825	1
FUNDA DCC-520 GREY (PS A3500-3400/2600-2500)	0036X399	8714574582832	1
FUNDA DCC-520 PINK (PS A3500-3400/2600-2500)	0036X400	8714574582849	1
FUNDA DCC-550 BLUE (D20)	0036X940	8714574584614	1
FUNDA DCC-550 SILVER (D20)	0036X942	8714574584638	1
FUNDA DCC-550 YELLOW (D20)	0036X941	8714574584621	1
FUNDA DCC-950 (SX410-400-510-500)	0037X615	8714574592121	1
FUNDA DCC-970 (SX510 HS/500 IS)	0037X614	8714574592114	1
FUNDA DCC-2500 BLACK (PS SX530HS-SX710-SX610)	0038X887	8714574610320	1
FUNDA DCC-2000 (PS N)	0038X667	8714574606026	1
ESTUCHE PARA TODO TIEMPO AW-DC20	9756A001AA	4960999242101	1

### ANILLO DE CONVERSIÓN

ADAPTADOR PARA LENTES CONVERSoras LA-DC58B	8160A001AA	4960999173528	1
ADAPTADOR PARA LENTES CONVERSoras LA DC52G	1908B001AA	4960999416540	1
ADAPTADOR PARA LENTES CONVERSoras LA-DC58C	9142A001AA	4960999204000	1
ADAPTADOR PARA LENTES CONVERSoras LA-DC58D	9758A001AA	4960999242361	1
ADAPTADOR PARA LENTES CONVERSoras LA-DC58G	1172B001AA	4960999354170	1
ADAPTADOR PARA LENTES CONVERSoras LA-DC58H	1593B001AA	4960999400525	1
ADAPTADOR PARA LENTES CONVERSoras LA-DC58K	3151B001AA	4960999620770	1
ADAPTADOR PARA LENTES CONVERSoras LAH-DC10	9223A001AA	4960999206479	1
ADAPTADOR PARA LENTES CONVERSoras LA-DC10	9610A001AA	4960999216379	1
ADAPTADOR PARA LENTES CONVERSoras LA-DC58C	6927B001AA	4960999917702	1
ADAPTADOR PARA LENTES CONVERSoras LAH-DC20	0301B001AA	4960999277110	1
ADAPTADOR DE FILTROS FA-DC58D (G16-15)	6925B001AA	4960999917672	1
ADAPTADOR DE FILTROS FA-DC58B (G12)	4721B001AA	4960999676524	1
ADAPTADOR DE FILTROS FA-DC67A	4728B001AA	4960999677187	1
ADAPTADOR DE FILTROS FA-DC58C (G1X)	5971B001AA	4960999840154	1
PARASOL LH-DC30 (G6)	9759A001AA	4960999242378	1
PARASOL LH-DC60 (SX30IS)	4727B001AA	4960999677163	1
PARASOL LH-DC90	9843B001AA	4549292017755	1
PARASOL LH-DC70 (G1X)	5973B001AA	4960999840192	1
PARASOL LH-DC100 & ADAPTADOR FILTROS FA-DC67B	0569C001AA	4549292038040	1

### CONVERSOR TELE

TELECONVERTIDOR TC-DC52	7636A001AA	4960999044668	1
TELECONVERTIDOR TC-DC10	9609A001AA	4960999216362	1
TELECONVERTIDOR TC-DC58D	3152B001AA	4960999620794	1
TELECONVERTIDOR TC-DC58E	6926B001AA	4960999917658	1

### CONVERSOR GRAND ANGULAR

CONVERTIDOR ANGULAR WC-DC52	6866A001AA	4960999003702	1
CONVERTIDOR ANGULAR WC-DC58B	1595B001AA	4960999400549	1
CONVERTIDOR ANGULAR WC-DC52A	9222A001AA	4960999206455	1

### FLASH

FLASH HF-DC2(SX530-710-610/IXUS275-170-165-160)	5189B001AA	4960999782232	1
FLASH HF-DC1	9940A001AA	4960999250137	1
SOPORTE FLASH BKT-DC1	3412B001AA	4960999640587	1

### CARACA SUBMARINA

ESTUCHE ESTANCO AL AGUA WP-DC32 (IXUS110IS)	3602B001AA	4960999637051	1
ESTUCHE ESTANCO AL AGUA WP-DC13 (IXUS110IS)	1970B001AA	4960999417448	1
ESTUCHE ESTANCO AL AGUA WP-DC36 (IXUS105IS)	4264B001AA	4960999660202	1
ESTUCHE ESTANCO AL AGUA WP-DC35 (S90IS)	4041B001AA	4960999651453	1
ESTUCHE ESTANCO AL AGUA WP-DC34 (G12& G11)	4042B001AA	4960999654652	1
ESTUCHE ESTANCO AL AGUA WP-DC31 (IXUS100IS)	3601B001AA	4960999637020	1
ESTUCHE ESTANCO AL AGUA WP-DC29 (IXUS95IS)	3466B001AA	4960999631530	1
ESTUCHE ESTANCO AL AGUA WP-DC38 (S95IS)	4712B001AA	4960999675343	1
ESTUCHE ESTANCO AL AGUA WP-DC39 (IXUS115HS)	4720B001AA	4960999676494	1
ESTUCHE ESTANCO AL AGUA E WP-DC18 (A650IS)	2315B001AA	4960999530017	1
ESTUCHE ESTANCO AL AGUA WP-DC17 (IXUS 860IS)	2318B001AA	4960999485362	1
ESTUCHE ESTANCO AL AGUA WP-DC16 (A720IS)	2314B001AA	4960999484389	1
ESTUCHE ESTANCO AL AGUA WP-DC15 (IXUS950)	2050B001AA	4960999450087	1
ESTUCHE ESTANCO AL AGUA WP-DC27 (IXUS980IS)	3201B001AA	4960999620763	1
ESTUCHE ESTANCO AL AGUA WP-DC26 (IXUS870IS)	3202B001AA	4960999620992	1
ESTUCHE ESTANCO AL AGUA WP-DC54 (G7X)	9837B001AA	4549292020649	1
ESTUCHE ESTANCO AL AGUA WP-DC320L (IXUS220HS)	5188B001AA	4960999782201	1
ESTUCHE ESTANCO AL AGUA WP-DC47 (S110)	6938B001AA	4960999918242	1
ESTUCHE ESTANCO AL AGUA WP-DC48 (G15)	6924B001AA	4960999917627	1
ESTUCHE ESTANCO AL AGUA WP-DC49 (SX280-270 HS)	8369B001AA	4960999979656	1
ESTUCHE ESTANCO AL AGUA WP-DC51 (S120)	8723B001AA	4960999989617	1
ESTUCHE ESTANCO AL AGUA WP-DC52 (G16)	8722B001AA	4960999991375	1
ESTUCHE ESTANCO AL AGUA WP-DC310L (IXUS115HS)	5191B001AA	4960999782317	1

ESTUCHE ESTANCO AL AGUA WP-DC37 (IXUS130IS)	4265B001AA	4960999660233	1
ESTUCHE ESTANCO AL AGUA WP-DC330L (IXUS125HS)	5709B01AA	4960999844336	1
ESTUCHE ESTANCO AL AGUA WP-DC53	9516B001AA	4549292009842	1
ESTUCHE ESTANCO AL AGUA WP-DC46 (SX240/260)	6250B001AA	4960999846194	1
ESTUCHE ESTANCO AL AGUA WP-DC45 (D20)	5708B001AA	4960999844725	1
ESTUCHE ESTANCO AL AGUA WP-DC44 (G1X)	5969B001AA	4960999819808	1
ESTUCHE ESTANCO AL AGUA WP-DC43 (S100)	5481B001AA	4960999790435	1
ESTUCHE ESTANCO AL AGUA WP-DC42 (SX220/230)	5066B001AA	4960999786063	1
ESTUCHE ESTANCO AL AGUA WP-DC41 (IXUS220HS)	5187B001AA	4960999780757	1
ESTUCHE ESTANCO AL AGUA WP-DC340L (IXUS500HS)	6231B001AA	4960999844503	1
LASTRES PARA ESTUCHES ESTANCOS WW-DC1	9876A001AA	4960999246727	1
FLOTADOR FT-DC1 (D30)	9557B001AA	4549292012422	1

#### CORREA

CORREA DE CUERO	0811V245	8714574971063	1
CORREA METÁLICA	0361V842	8714574921341	1
CORREA DE CUELLO NS-100 (PARA N100)	0039X579	8714574617268	1
CORREA PARA HOMBRO Y CUELLO STP-DC1 (D10)	3916B001AA	4960999640327	1
CORREA CON MOSQUETON STP-DC2 (D10)	3917B001AA	4960999640334	1
CONJUNTO DE CUBIERTA FRONTAL FC-DC1	3918B001AA	4960999640341	1
AKT-DC2 ACCESORIOS D20	6243B001AA	4960999844794	1

#### OTROS

VISOR ELECTRÓNICO EVF-DC1	9555B001AA	4549292013061	1
---------------------------	------------	---------------	---

#### ACCESORIOS SELPHY

##### CONSUMIBLES CP

RP-108 TARJETA POSTAL 108 HOJAS	8568B001AA	4960999980034	1
KC-18IS ADHESIVOS CUADRADOS (54X54MM) 18 HOJAS	7429B001AA	4960999922171	1
KC-18IF ETIQUETAS TARJETA DE CRÉDITO 18 HOJAS	7741A001AH	4960999047072	1
KC-36IP TARJETA DE CREDITO 36 HOJAS	7739A001AH	4960999047058	1
KP-36IP TARJETA POSTAL 36 HOJAS	7737A001AH	4960999047034	1
KP-108IN TARJETA POSTAL 108 HOJAS	3115B001AA	4960999616889	1

##### CONSUMIBLES ES

P25BW (ES3/30/40) TARJETA POSTAL	1251B001AA	4960999354897	1
E-P100 (ES3/30/40) TARJETA POSTAL	1335B001AA	4960999357003	1
E-C25 (ES3/30/40) TARJETA DE CREDITO	1249B001AA	4960999354873	1
RP-1080V (PARA SELPHY CP910 Y CP820)	8569B001AA	4960999980065	1

#### BATERIA

BATT_PACK NB-CP2L (CP780/790/800/810)	0188B001AB	4960999258980	1
---------------------------------------	------------	---------------	---

#### BOLSAS

FUNDA SELPHY DCC-CP2 BEIGE	0030X597	8714574532271	1
FUNDA SELPHY DCC-CP2 GRIS	0035X550	8714574577135	1
FUNDA SELPHY DCC-CP3 BLACK	0039X580	8714574617275	1

#### OTROS

CASETE PCL-CP300 (CP780/790/800)	2561B001AA	4960999570914	1
CASETE PCC-CP400 (810/820/900/910)	6202B001AA	4960999846941	1
CASETE PCC-CP300 (CP780/790/800)	2562B001AA	4960999570921	1